



DESPIECE BET DIA 251 R PP-PVDF



POS. POS.	DESCRIPCIÓN	DESCRIPTION	Cantidad Quantity
1	Monobloque central	Main block	
3	Cuerpo de la bomba	Pump casing	
4	Colector	Manifold	
5	Asiento de bola	Ball seat	
5b	Jaula de guía de la bola	Ball runner cage	
6	Eje	Shaft	
8	Platina interna	Internal cap	
9	Arandela Belleville	Belleville washer	
10	Tuerca de bloqueo	Cap	
11	Bola	Ball	
12	Membrana interna	Internal diaphragm	
13	Membrana externa	External diaphragm	
15	Filtro silenciador	silencer filter	
16	Anillo de parada	Stop ring	
17	Guarnic. asiento bola	Ball seat packing	
17a	Guarnición	Packing	
18	Tapa del colector	Manifold cap	
19	Intercambiador neumático	Exchanger	
20	Tornillo silenciador	Silencer screw	
21	Separador	Spacer	
22	Rejilla del silenciador	Silencer screen	
23	Tuerca con brida	Flanged nut	
26	Tornillo del cuerpo de la bomba	Pump casing screw	
27	Guarnición tapa colector	Manifold cap packing	
28	Tornillos para colector	Manifold screw	
29	Arendela	Washer	
40	Tapa de polietileno	Polyethylene cup	

DESPIECE BET DIA 251 R ALUMINIO




POS. POS.	DESCRIPCIÓN	DESCRIPTION	Cantidad Quantity
1	Monobloque central	Main block	
3	Cuerpo de la bomba	Pump casing	
4	Colector	Manifold	
5	Asiento de bola	Ball seat	
5b	Jaula de guía de la bola	Ball runner cage	
6	Eje de conexión	Connection shaft	
8	Platina interna	Internal cap	
9	Arandela Belleville	Belleville washer	
10	Tuerca de bloqueo	Cap	
11	Bola	Ball seat	
12	Membrana interna	Internal diaphragm	
13	Membrana externa	External diaphragm	
15	Filtro silenciador	Silencer filter	
16	Anillo de parada	Stop ring	
17	Guarnic. asiento bola inf.	Ball seat packing low	
17a	Guarnic. asiento bola sup.	Ball seat packing up.	
18	Tapa del colector	Manifold cap	
19	Intercambiador neumático	Pneumatic exchanger	
20	Tornillo silenciador	Silencer screw	
21	Separador	Spacer	
22	Rejilla del silenciador	Silencer screen	
23	Tuerca	Bolt	
26	Tornillo del cuerpo de la bomba	Pump casing screw	
27	Guarnición tapa colector	Manifold cap packing	
28	Tornillos para colector	Manifold screw	
29	Arendela	Washer	
30	Anillo separador	Spacer ring	
40	Tapa de polietileno	Polyethylene cup	



**BOMBAS ESPECIALES
TORRES**

DESPIECE BET DIA 251 R INOX



POS. POS.	DESCRIPCIÓN	DESCRIPTION	Cantidad Quantity
1	Monobloque central	Main block	
3	Cuerpo de la bomba	Pump casing	
4a	Colector aspiración	Manifold (intake)	
4b	Colector descarga	Manifold (delivery)	
5	Asiento de bola	Ball seat	
5b	Jaula de guía de la bola	Ball runner cage	
6	Eje	Shaft	
8	Arendela lado aire	Air-side cap	
9	Arandela Belleville	Belleville washer	
10	Tuerca de bloqueo	Cap	
11	Bola	Ball seat	
12	Membrana interna	Internal diaphragm	
13	Membrana externa	External diaphragm	
15	Filtro silenciador	Silencer filter	
16	Anillo de parada	Stop ring	
17	Guarnic. asiento bola inf.	Ball seat packing low	
17a	Guarnic. asiento bola sup.	Ball seat packing up.	
19	Intercambiador neumático	Pneumatic exchanger	
20	Tornillo silenciador	Silencer screw	
21	Separador	Spacer	
22	Rejilla del silenciador	Silencer screen	
23	Tuerca	Bolt	
26	Tornillo del cuerpo de la bomba	Pump casing screw	
28	Tornillos para colector	Manifold screw	
29	Arendela	Washer	
30	Anillo separador	Spacer ring	
45	Pata	Feet	
46	Tornillo de la pata	Feet-screw	