


DESPIECE

BET DIA 503 R PP-PVDF




POS. POS.	DESCRIPCIÓN	DESCRIPTION	Cantidad Quantity
1	Monobloque central	Central body	
2	Brida lado aire	Flange air side	
3	Cuerpo de la bomba	Pump casing	
4	Colector	Manifold	
5	Asiento de bola	Ball seat	
5b	Jaula de guía de la bola	Ball runner cage	
6	Eje	Shaft	
7	Silenciador	Silencer	
8	Platina interna	Internal cap	
9	Arandela Belleville	Belleville washer	
10	Tuerca de bloqueo	Cap	
11	Bola	Ball	
12	Membrana interna	Internal diaphragm	
13	Membrana externa	External diaphragm	
17	Guarnic. asiento bola inf.	Ball seat packing low	
17a	Guarnic. asiento bola sup.	Ball seat packing up	
18	Tapa del colector	Manifold cap	
19	Intercambiador	Exchanger	
21	Separador	Spacer	
23	Tuerca	Bolt	
25	Tornillo central	central screw	
26	Tornillo del cuerpo de la bomba	Pump casing screw	
27	Guarnición tapa colector	Manifold cap packing	
28	Tornillos para colector	Manifold screw	
29	Arandela	Washer	
37	Arandela	Washer	
47	Tuerca con brida para central	flanged nut for central	
48	Clavija	pin	



**BOMBAS ESPECIALES
TORRES**

DESPIECE BET DIA 503 R ALUMINIO




POS. POS.	DESCRIPCIÓN	DESCRIPTION	Cantidad Quantity
1	Monobloque central	Main block	
2	Brida lado aire	Flange air side	
3	Cuerpo de la bomba	Pump casing	
4a	Collettore sup.	Manifold (up)	
4	Collettore Inf.	Mainfold (low)	
5	Asiento de bola	Ball seat	
6	Eje	Shaft	
7	Silenciador	Silencer	
8	Platina interna	Internal cap	
9	Arandela Belleville	Belleville washer	
10	Tuerca de bloqueo	Cap	
11	Bola	Ball	
12	Membrana interna	Internal diaphragm	
13	Membrana externa	External diaphragm	
17	Guarnic. asiento bola inf.	Ball seat packing low	
17a	Guarnic. asiento bola sup.	Ball seat packing up	
19	Intercambiador	Exchanger	
21	Separador	Spacer	
23	Tuerca	Bolt	
25	Tornillo central	central screw	
26	Tornillo del cuerpo de la bomba	Pump casing screw	
28	Tornillos para colector	Manifold screw	
29	Arandela	Washer	
37	Arandela	Washer	
38	Arandela Belleville	Belleville washer	
50	Clavija	Pin	
51	Tornillo	Screw	
52	Adaptador etiqueta	Adapter label	



BOMBAS ESPECIALES
TORRES

DESPIECE

BET DIA 503 R AISI 316



POS. POS.	DESCRIPCIÓN	DESCRIPTION	Cantidad Quantity
1	Monobloque central	Main block	
2	Brida lado aire	Flange air side	
3	Cuerpo de la bomba	Pump casing	
4 b	Colector sup.	Manifold (up)	
4 a	Colector Inf.	Manifold (low)	
5	Asiento de bola	Ball seat	
6	Eje	Shaft	
8	Platina interna	Internal cap	
9	Arandela Belleville	Belleville washer	
10	Tuerca de bloqueo	Cap	
11	Bola	Ball	
12	Membrana interna	Internal diaphragm	
13	Membrana externa	External diaphragm	
17	Guarnic. asiento bola inf.	Ball seat packing low	
17 a	Guarnic. asiento bola sup.	Ball seat packing up	
19	Intercambiador	Exchanger	
21	Separador	Spacer	
23	Tuerca	Bolt	
25	Tornillo central	central screw	
26	Tornillo del cuerpo de la bomba	Pump casing screw	
28	Tornillos para colector	Manifold screw	
29	Arandela	Washer	
37	Arandela	Washer	
38	Arandela Belleville	Belleville washer	
45	Pata	Feet	
46	Tornillo de la pata	Feet-screw	
47	Tuerca	Bolt	
50	Clavija	Pin	
51	Tornillo	Screw	
52	Adaptador etiqueta	Adapter label	